

PT-230CR

Instructions:

To fill gas tank:

Turn unit upside down and firmly push the butane can nozzle into the filling valve (fig.D) The tank should be filled in approximately 15 seconds. Please allow a few minutes after filling for the gas to stabilize.

To ignite torch:

1. Make certain that Hands Free Lever (C) is positioned in the down position
2. Rotate the gas control knob (B) approx 1/2 between the + and -.
3. Rotate the Igniter Button (A) counterclockwise (to the left) and while rotated push Button using thumb.
4. With Thumb pushed on igniter button, slide the Hands Free Lever (C) upwards. You may now remove thumb from Igniter Button for Hands Free use.
5. The flame size can then be adjusted by rotating the gas control knob (B) in either direction.
6. The flame temperature may be adjusted by rotating the Air Control Ring (E)
7. To shut off torch, move Hands Free Lever (C) to the down position.

